


Quick Reference Guide

MaxiLink ML629

Thank you for purchasing AUTEL tool. Manufactured to a high standard, our tool will, if used according to these instructions and properly maintained, give you years of trouble-free performance.

Getting Started





Please download the Maxi PC Suite from

www.autel.com > Support & Updates > Firmware & Downloads > Update Client, and install to your Windows-based computer.

Software Update and Delete

1 Image: Constraint of the second s	<image/> <page-header><text><list-item><list-item></list-item></list-item></text></page-header>
	<page-header><page-header><page-header><page-header><page-header><page-header><image/><text></text></page-header></page-header></page-header></page-header></page-header></page-header>

Data Printing

- Connect the device to the computer with the USB cable supplied.
- Run Autel Printer on the computer which is installed after the installation of Maxi PC Suite.
- Select Playback function in the Main Screen of the tool. On the data menu screen, use the UP/DOWN scroll button to select the data you want to print. Wait for the review window to display, and then select Print function.
- The selected data will display on the textbox of the Autel Printer. By selecting the function keys on the right, you could execute the following operations:

Print – print all data in the textbox. (A printer should be connected to the computer.)

Edit - display an editable NOTEPAD window with recorded data.

Copy - copy data in the textbox to the clipboard.

Clear - delete data in the textbox.

Exit – quit the operation.

For service and support, please contact us.

http://pro.autel.com / www.autel.com / support@autel.com 0086-755-86147779 (China HQ) / 1-855-288-3587/1-855-AUTELUS (North America) 0049 (0) 61032000522 (Europe) / (+507) 308-7566 (South America) / 03 9480 2978 / +61 476293327 (Australia)